


Reading the Iskraemeco ME372 Meter


The display scrolls automatically without the need to press any buttons on the meter.




0.9.1 Current Time
(BST or GMT depending on tarriff)




0.9.2 Current Date YY:MM:DD



1.8.1 R1. kWh; 1.8.2 R2
1.8.3 R3 etc. may follow



1.8.0 Total kWh



Other displays may follow before returning to the current time