

How to read a L&G SMETS 2 E470 meter

The main screen on the meter is already defaulted to the Import Register which shows your reading. Please use this when submitting your meter reading.



Steps for Rate 2 customers:

1. From the main screen, press and hold the button B, this will take you to the Tariff Display List
2. The first screen will show you the first rate
3. Pressing button A will show you the next rate